



Foot for attaching 6x30 and 9x50 finders to the telescope tube. Comes with M4 screws screwed into the tube.