

teleskopy.pl



Glass lenses to replace in case of damage (eg scratches, breaks) of the HD Hero 3 camera lens. Includes 2 lenses, 2 gaskets, screws and a screwdriver.