

teleskopy.pl



The Camrock X41 photo bag is the perfect solution for people who want to transfer their photographic equipment in a convenient and safe way. It can easily accommodate a DSLR with a standard lens, two additional lenses / flash and other accessories. It has two adjustable and adjustable dividers, so that the inside of the bag can be configured in many ways (the whole can be divided into 1, 2 or 3 parts in different settings). There are also three additional pockets and inserts for documents, pens, etc. The bag in addition to the attractive look offers functionality and practicality thanks to the very good performance and use of durable, waterproof materials (nylon 1680D TXP). All the walls of the bag are stiffened. dimensions â€¢ external: 33 cm / 20 cm / 20 cm (length / width / height) â€¢ internal: 23 cm / 12 cm / 15 cm (length / width / height) Characteristics â€¢ compact design, small external dimensions â€¢ removable and lengthwise adjustable shoulder strap â€¢ a comfortable handgrip to hold the bag in your hand â€¢ possibility of configuring up to 3 chambers inside the bag â€¢ large outer pocket closed with a zipper with pockets for documents, pens, etc. â€¢ two side pockets with zippers â€¢ large capacity of the bag - can accommodate a DSLR camera with a lens, an additional lens, a lamp + other accessories â€¢ the interior of the bag lined with soft material â€¢ high quality of 1680D TXP waterproof nylon â€¢ all walls of the bag stiffened, filled with foam â€¢ metal buckles â€¢ rubber pads underneath the bag so that the bag can be put on a wet surface The Camrock X41 bag thanks to its regular shapes is very handy while keeping the exceptionally large space inside. It can also be successfully used to carry cameras with accessories. Kompatybilno?æ List of cameras in the bag: â€¢ Canon EOS 550D 500D 450D 400D 350D 300D 1000D 7D 60D 50D 40D 30D 20D 10D 5D â€¢ Fujifilm FinePix IS Pro FinePix IS-1 FinePix S5 Pro FinePix S3 Pro S9600 S9500 S100fs â€¢ Minolta 5D 7D â€¢ Nikon D40X D40 D60 D50 D80 D90 D70s D70 D7000 D300 D3100 D300 D300 D200 D100 â€¢ Olympus E-620 E-520 E-510 E-500 E-450 E-420 E-410 E-400 E-330 E-300 â€¢ Pentax K-7 K-5 Kr Kx K200D K20D K100D Super K10D K110D * ist DL2 * ist DS2 â€¢ Sony Alpha A700 A560 A550 A550 A500 A450 A390 A380 A350 A300 A290 A230 A200 A55 A33 â€¢ Sony Alpha NEX-5 NEX-3 and most of the others.