



The most convenient to use! The photo level allows correct positioning of the camera in the horizontal (or vertical) plane when taking vertical photographs. Thanks to this, your photos will always be properly cropped to the horizon. Especially useful when photographing architecture, landscapes and creating panoramas. Easy to install, slides into the flash mounting rail. It is more accurate than the levels built into tripods. Warranty 2 years